612400

2009-2014 RAM 1500 W/ 2 PIECE DRIVE SHAFT

CARRIER BEARING SPACER

PARTS LIST:

8368SP ALUMINUM SPACER	12
M10-1.5 X 70 HEX CAP SCREW	4
M10 FLAT WASHER	4

- 1) UNBOLT THE 4 BOLTS THAT ATTACH THE CARRIER BEARING TO THE FRAME CROSS MEMBER
- 2) INSERT 3 SPACERS PER BOLT AND RE-ATTACH THE CARRIER BEARING USING THE 4 PROVIDED BOLTS AND WASHERS

