



McGaughy Store
(800) 764-0926
www.mcgaughystore.com

MOTOR MOUNT INSTRUCTIONS 1955-57 FULLSIZE CAR

These mounts are designed for bolt in use under normal conditions. If you are using a high performance engine we suggest welding them in.

1. Install mounts with front edge against crossmember rivet. Use the bolt supplied with the mounts to do so.

Hole A = 1955

Hole B = 1956 & 1957

2. Drill through top holes through the frame and install the bolts supplied with the mounts.

3. Brake lines may need to be re-positioned.

4. Rubber Motor Mounts to be used are for 69-72 Chevelle or Camaro or Full-size passenger car with a small block engine..

5. Some repositioning may be necessary to ease in the installation of the engine.