



# **STOP -- READ THIS FIRST**

INSTRUCTIONS FOR McGAUGHY'S 04 FORD LEAF SPRINGS

## **REAR 4" LEAFS**

Once you have your stock leaf springs unbolted and out of the vehicle you will need to remove the stock retaining piece for the U-bolts. Make sure you put clamps on both ends of the leaf spring to hold the leaves from exploding apart. Unbolt the stock retaining piece off the center of the stock leaf spring. Once you have clamped both ends of the McGaughy's leaf spring, unbolt the two center studs and install your factory retaining piece. Install new McGaughy's leaf springs just how the original leaves came out.

## **REAR SHOCK EXTENDERS**

Install the new shock extenders around the original shock mount, extending it downwards, and use the hardware that is provided. Use the stock shock bolt and reinstall the factory shocks. Tighten to 60 lbs.

Install the new bump stops that are provided in the kit. Remove the factory shim that is between the carrier bearing and the frame. Reinstall the carrier bearing.