

832510

INSTALLATION INSTRUCTIONS

*A STRUT COMPRESSOR IS REQUIRED FOR SAFE STRUT DISASSEMBLY

- 1) FOLLOW THE STRUT SPACER INSTALLATION INSTRUCTIONS FOR STRUT REMOVAL
- 2) ONCE THE STRUT IS OUT, USE A STRUT COMPRESSOR TO SAFELY COMPRESS THE COIL AND REMOVE THE STRUT TOP BY LOOSENING AND REMOVEING THE SINGLE NUT AT THE CENTER OF THE UPPER MOUNT. (THE COIL IS UNDER EXTREME LOAD, SO **DO NOT** ATTEMPT THIS STEP WITH OUT A STRUT COMPRESSOR)
- 3) THE MAXTRAC COIL SPACER WILL GO AT THE TOP OF THE COIL, BETWEEN THE PLASTIC ISOLATOR THAT THE COIL RESTS AGAINST AND THE RUBBER PAD THAT IS JUST ABOVE THAT.
- 4) COMPRESS THE COIL A BIT MORE TO MAKE ROOM FOR THE SPACER, INSTALL THE STRUT TOP, AND TIGHTEN THE NUT DOWN ALL THE WAY ENSURING THAT THE TOP IS ALIGNED EXACTLY AS IT CAME OFF.
- 5) PROCEED NOW TO THE STRUT SPACER INSTALLATION

